RMG AUTOMATION
+91 9940594413

Smart Water Tank Level Monitoring System

Model : SMWLI-150

User Manual

Version 2.0-10/22

http://rmgautomation.com
rmgworld@hotmail.com

1. INTRODUCTION

IoT (Internet of Things) technology is currently being used in abundance across industries. IoT is the future, with many societal benefits. It is a full-fledged solution, comprising customizable and flexible features for ease of use. The rapid acceptance of technology in the water industry is a bold step toward progress, which makes a great impact on overall productivity. We feel proud to say that we are one among the handful leading manufacturers launching the, "IOT based Smart Water Level Indicator."

Here you go!!! This product needs internet/Wi-Fi to work with. As such, this device can be controlled from any nook and corner of the world. You just need to have internet in the vicinity of the product. There is a special mention that our RMG smart water level controller can be controlled by "n" number of users and in one mobile app, each user can monitor & control "n" number of devices at one point. Live Motor Pump Status, water level with user friendly programmable settings are available.

We are unique among other brands in assured quality, affordable pricing and customized solutions where we update the Firmware Over-The-Air – "FOTA" providing ease and comfort to the users.

2. DESCRIPTION

- **Power ON/OFF switch:** This switch is provided at the bottom side to switch ON/OFF the indicator unit.
- **Power ON LED:** It indicates the power supply to the unit.
- **SIGNAL LED:** It refers to the connection between the cloud server and the device. Flashes permanently when a connection is available. If there is no connection, the LED will blink.

3. TOOLS REQUIRED

- 3 pair or 6 core communication cable.
- Drilling Machine
- Simple hammer
- Wooden gattas
- Screws for mounting units on wall
- Line tester
- Wire stripper,
- Insulation tape

3. WiFi CONFIGURATION

- Connect AC supply 230V to red and black wire of the indicator. Power on the device.
- **Power ON** LED is turned ON.
- **Signal LED** on the indicator blinks
- In your PC or Phone, Check the available WiFi networks. WiFi list shows RMG Smart WLI's name **RMG_XXXXXXXXXXXX**. If it is not displayed refresh your WiFi connected devices list.
- Click on **RMG_XXXXXXXXXXXX** and it redirects to the browser to configure wifi.(figure 1).
- If it is not re-directed, type 192.168.4.1 in the address bar of browser. You get the configure wifi page.(figure 2).
- Click on **Configure WiFi**. This will lead you to figure.3
- Here, you will see the list of wifi networks available. Click **Refresh** button, if it is not displayed. Select your SSID and type the respective password.
- Click **Save** to store the credentials in the device. Once the credentials are saved, you get the page as shown in figure 4.
- The **Signal LED** glows constantly in a few seconds. It indicates that the Smart Device is connected to the RMG cloud server.
- Thus WiFi configuration process is now completed succesfully



Figure 1



Figure 2



Figure 3

Figure 4

4. APPLICATION CONFIGURATION



Figure 5

- Go to play store in your Android phone.
- Search for "**RMG Smart Water Tank**" application.(figure 5)
- Install the **Smart Water Tank** application.(figure 6) and open it.
- You will see the login screen as in figure 7.



Figure 6

Figure 7

- Enter the details asked, Your Name, Your Gmail ID and Your Mobile Number. Then Click Login.
- A screen appears asking for OTP (figure.8), You will also get an OTP. Enter the OTP and click on **Verify OTP**.
- Now, You will lead to Home page (figure.9), where you can add your device.
- Click **Add Device** option in Home page.
- Now a window opens as in figure 10. In this click on **SCAN QR CODE tab** and Scan the QR code given on the product. If you are unable to scan, Enter the Serial No. and Activation Code given and save it.
- Now, You can see the connected indicator in your App. You can also see the **Alarm** setting options and a **Mute** button to mote the alarm (figure.11).
- By clicking the in the screen, You can change the name of your tank, and set the **Tank Low Level Alarm** and **Tank High Level Alarm** percentages (figure.12).



Figure 8

Figure 9



Figure 10



Figure 11

Figure 12

4. INSTALLATION PROCEDURE

Caution: Switch off the main power while doing the Power Connection.

Step 1: Wall mount the Smart Water Level Indicator unit in the desired location. Make sure wifi/internet is available in the vicnity.
Step 2: Connect AC supply 230V to red and black wires of the indicator as shown in the figure 13.

figure.12. Power connection

figure.13. Sensor connection

Note: In case of doubts please call 044 - 43180017 or What's App 9940594413 from Monday to Friday 10 am to 6 pm.
Step 3: Lay 6 core cable between indicator and tank. Join one end of the 6 core cable to sensor line of indicator as per label. In tank side, **Contact type sensor connection:** Take the sensors and cut them according to the levels of tank and join them with the 6 core cable as per label coded.(Refer figure. 13) **Magnetic float sensor connections:** These Sensor has 2 wires, Use any one wire in each sensor as common. Other wires left in each can be used for levels. Join them with the 6 core cable as per label coded.
Step 4: Immerse the Sensors inside the Over Head Tank (OHT) and tape it. Sensors should be in 20%, 40%, 60%, 80% and 100% of tank. (Refer figure. 13) This completes installation.

5. OPERATING PROCEDURE

- Turn on the Power On/OFF switch in your controller. Power ON LED will glow.
- Confirm Signal LED glows permanently, indicates that device is connected to RMG Cloud Server.
- Now Open the RMG Smart Water Tank App from your mobile.
- Depending upon the water levels in the tank, the live level indications of the tank can be seen on your app.
- When the tank level goes below 20% and when it reaches 100% buzzer alarm can be heard. Buzzer can be muted through app.
- There is options for selecting the buzzer alarm at the desired level.

6. TROUBLE SHOOTING METHODS

Sl No	**Error**	**Solutions**
1	Device dead / Not Powered ON	**a.** Check the power connection to device. **b.** If problem continues, contact RMG for support.
2	Signal LED blinks continuously	It means, the Smart Device is not connected with RMG Cloud Server. **a.** Check whether the WiFi is available. **b.** Check whether internet connection is available.